


Access to the house



The PinPad is located on the left side of the house wall next to the front door.

Instructions

Open with pin code

- Touch the star key (1) until the number field lights up.
- Enter PIN & confirm with key (2).

Open with transponder

- Hold the transponder with the flat side against the center of the number field (3).
- The front door unlocks and opens.